









































ENIGMA COOKER

	NSA140	Oven shelf PCO0295 SIZE: 460mm x 310mm	 More Info  Add to order
	NSA131	Grill pan only 275mm x 330mm, MAC0044	 More Info  Add to order
	NSA132	Grill pan trivet, 202mm x 243mm, PCC1190	 More Info  Add to order
	NSA161	Grill pan handle PCC1186	 More Info  Add to order
	NSA162	Oven thermostat.	 More Info  Add to order
	NSA144	Hob Control Tap (OH96991)	 More Info  Add to order
NSA143		Grill Control Tap (OH96991)	 More Info  Add to order
	NSA164	Oven thermocouple PCO0159	 More Info  Add to order
	NSA163	Spark generator box PCC1391 (ENIGMA, ECLIPSE AND OTHERS)	 More Info  Add to order
	NSA165	Grill thermocouple PCC1154	 More Info  Add to order
	NSA166/S	Burner thermocouple Front (short) PCC1163	 More Info  Add to order
	NSA166/L	Burner thermocouple Rear (long) PCC1168	 More Info  Add to order
	NSA164/SPD	Oven Thermocouple (SPCC1121) Spade Connection Type	 More Info  Add to order

	NSA167	Small Burner cap PCC0823	 More Info  Add to order
	NSA168	Small Burner skirt PCC0822	 More Info  Add to order
	NSA165/SPD	Grill thermocouple (SPCC1125). Spade connection type.	 More Info  Add to order
	NSA109	Burner cap PCC0803	 More Info  Add to order
	NSA110	Burner skirt PCC0802	 More Info  Add to order
	NSA169	Oven burner bar MAO0061	 More Info  Add to order
	NSA195	Grill Burner	 More Info  Add to order
	NSA146	Oven Electrode and lead (SPCC1430)	 More Info  Add to order
	NSA147	Grill Electrode and lead (SPCC1417)	 More Info  Add to order
	NSA148	Rear Hob Electrode and lead (SPCC1453)	 More Info  Add to order
	NSA149	Front hob electrode and lead (SPCC1455)	 More Info  Add to order
	NSA175	Inner Door Glass, 19 1/2" x 14 1/2"	 More Info  Add to order
	NSA196	Grill Door	 More Info  Add to order

BLACK &
SILVER

	NSA142	Grill Jet (SPCC0775)		More Info Add to order
	NSA171	Oven door in parchment.		More Info Add to order
	NSA170	Oven door in silver and black.	<i>BLACK & SILVER</i>	More Info Add to order
	NSA179	Oven door in black.	<i>BLACK</i>	More Info Add to order
	NSA141	Oven door seal PCO0248		More Info Add to order
	NSA172	Pan support clips, PCC0647		More Info Add to order
	NSA173	Ignition Button	<i>BLACK</i>	More Info Add to order
	NSA193/L	Lower door hinge.		More Info Add to order
	NSA193/U	Upper door hinge.		More Info Add to order
	NSA193/BH	Oven door hinge bush.	<i>BLACK PLASTIC</i>	More Info Add to order
	NSA193/PN	Oven door pin.		More Info Add to order
	NSA159	Glass Lid Assembly (SG900.BK)		More Info Add to order
	NSA158	Lid Isolation Valve (SPCC0500)		More Info

 [Add to order](#)



NSA176

Oven Door Catch

*STAINLESS
STEEL*

 [More Info](#)

 [Add to order](#)



NSA178

Gas control knob.

BLACK

 [More Info](#)

 [Add to order](#)

NSA145

Pan Support
(OH96991)

 [More Info](#)

 [Add to order](#)